

Per la duplicazione è necessario un radiocomando perfettamente funzionante.

1. Avvicinarsi alla centralina ricevente (5 mt)
 2. Premere e mantenere premuto il primo tasto del nuovo radiocomando fino a che il led si spegne, quindi rilasciare il tasto.
 3. premere e mantenere premuto il secondo tasto del nuovo radiocomando fino a che il led si spegne più due secondi, quindi rilasciare il tasto.
 4. premere e mantenere premuto il primo tasto del vecchio radiocomando fino a che il led si spegne, quindi rilasciare il tasto
 5. premere e mantenere premuto il secondo tasto del vecchio radiocomando fino a che il led si spegne.
- Il nuovo radiocomando è pronto.

For duplication is necessary one remote control perfect working .

1. Approach the receiving unit (5 meters)
 2. Press and hold the first key of the new remote control until the LED turns off, then release the button.
 3. Press and hold the second key of the new remote control until the LED turns off more than two seconds, then release the button.
 4. press and hold the first key of the old remote control until the LED turns off, then release the button
 5. press and hold the second key of the old remote control until the LED turns off.
- The new remote control is ready

