

Telecomando Mytho2 433MHZ autoapprendimento

itelecomandi.com

Copia di un codice

ITALIANO

Per prima cosa bisogna cancellare i codici esistenti



1) premere contemporaneamente il tasto A e B (il led non si deve accendere, se si accende vuol dire che non sono stati premuti contemporaneamente, in questo caso riprovare).

2) dopo circa 2 secondi il led emette un paio di lampeggi. **Tenendo sempre premuto il tasto A** rilasciare il tasto B, poi sempre senza lasciare il tasto A premere 3 volte in successione il tasto B. A questo punto il led inizia a lampeggiare regolarmente confermando la cancellazione di tutti i codici. A conferma di questo, premendo brevemente uno qualsiasi dei quattro tasti il led non si deve accendere.

3) per fare una copia mettere i due radiocomandi schiena contro schiena, premere il tasto dell'originale e poi il tasto del nuovo telecomando sul quale si vuole copiare il codice. Il led farà prima 2 lampeggi, poi 3 lampeggi, infine si accenderà in modo continuo a conferma della copia avvenuta. E' consigliabile tenere premuti i pulsanti per altri 5/6 sec.

In alcuni casi, secondo il tipo di telecomando da copiare, può essere necessario posizionare i due telecomandi testa contro testa o fianco a fianco.

Il segnale del telecomando di partenza deve essere alla massima potenza, se la copia non riesce sostituire la batteria nel telecomando originale.

Se l'operazione di copia non dovesse andare a buon fine ed il led non si accende ripetere l'operazione dal punto 2 provando a cambiare posizione ai due telecomandi. Per copiare altri codici sugli altri tasti ripetere l'operazione dal punto 3, senza rifare il reset.

Per sostituire le batterie svitare la vite posta sul retro in basso e fare leva, sfilare il contenitore nero dalla sede e togliere le batterie.

Non disperdere la batteria nell'ambiente!

Mytho 2 433 Mhz Auto Learn Remote Control



Copy of a code.

ENGLISH

First of all it's necessary to delete the existing codes.

1- press keys A and B at once (the led must not turn on. If led flashing you don't have pressed them together, try again)

2- After about 2 seconds the led blinks 3 times. Release key B still pressing key A, then press key B for 3 times in a row without releasing key A. Now the led blink regularly, all codes are erased. In order to confirm this, the led must not turn on pressing any of the four key just a moment.

3- To make a copy put the two remote control back to back, press the key of KEY4 remote control which you want to copy the code and then the key of the original one. First the LED will blink twice, then 3 times, then it will begin to flash fast, in order to confirm the copy to be carried out.

In some cases, according to the type of remote control to be copied, it can be necessary to place the two remote controls head to head or side by side.

If the copy process fails to be successful and the led doesn't ring repeat from point 3, try to change position to the two remotes or after changing the battery in the original one. If the led rings, but the remote control doesn't open, repeat from point 1.



In order to copy other codes and other keys, repeat the process from point 3.

To replace the batteries unscrew the screw on the lower back and pry. Dispose of the old battery in the correct manner and according to your local regulations.