

Questo telecomando è un ricambio unico e compatibile con tutti i modelli Electra e Airwell raffigurati.

Per impostare il telecomando procedere come segue:

- premere **contemporaneamente** i tasti **SET** e **MODE**;
 - nell'angolo in basso a sinistra del display lampeggerà il code number;
 - con i tasti "+" e "-" selezionare il codice che trovate sotto l'immagine del vostro modello e confermate premendo **SET**.
- Se all'immagine del vostro telecomando corrispondono più codici selezionate il primo, provate tutte le funzioni, se non rispondono passate al codice successivo.

This remote control is a unique replacement and compatible with all Electra and Airwell models pictured.

To set up the remote control follow the instructions:

- press the **SET** and **MODE** buttons **at the same time**;
- the code number will flash in the lower left corner of the display;
- with the "+" and "-" keys select the code found under the image of your model and confirm by pressing **SET**.

If several codes correspond to the image of your remote control, select the first one, try all the functions if they don't respond, move on to the next code.



CODE 01
RC-3



CODE 02
RC-7



CODE 03
RC-7I-1



CODE 04
YKR-M/001E



CODE 04
YKR-M/002E



CODE 05
RC-3 VAV



CODE 06
RC-4 HL



CODE 07
RC-41-1



CODE 08
RC-4 RCL




CODE 09
RC-41 RC



CODE 10
RC



CODE 11
RC-5



CODE 12
YKR-F/010



CODE 13
YKR-F/016E



CODE 14
YKR-F/015E



CODE 15
KFR A



CODE 15
KK9A-C25



CODE 16
YB0F



CODE 17
DG11J1-01



CODE 18
ELCO



CODE 19
P/N 435600



CODE 19
P/N 436000



CODE 20
Damper



CODE 21
RC-08A



CODE 22
RC-08B



CODE 23
RC-52A1/BGEF